



The machine consists of:

- N ° 1 motor (for the rotation of the drum)
- N ° 1 washing with solenoid valve

OPERATION

The motor of the drum of the EFD starts when the consent is given to the loading pump placed downstream of the machine.

When the pump shuts down, the EFD motor continues to rotate for 10 seconds.

The Wash works independently: from the moment the EFD drum motor starts, the wash works (solenoid valve opens) for 30 seconds every 3 minutes.

When the inlet loading pump is switched off, for the 10 seconds in which the EFD continues to rotate, the wash remains open for the same time.